



LAMP CIRCUIT
PUSH TO
RESET

CB1

PLAYFIELD CIRCUIT
PUSH TO
RESET

CB2

SCORE CIRCUIT
PUSH TO
RESET

CB3

1

2

3